

Instruction Manual
Smart Switch
Wi-Fi-RF-433

English

WRS-EU-MS-DE20

Product Description

This new designed glass panel wireless touch smart switch is designed with Wi-Fi+RF to replace traditional switches with a variety of ways to control. Now one smart feature is multi-control association to other smart switches is added into the MOES App together with the background light and stay status. And its scratch-resistant glass panel is suitable for different decoration styles with its best value.

Safety Information

Risk of Electric Shock: Electricity can cause personal injury and property damage if handled improperly. If you are not sure about any part of these instructions, please seek professional assistance from a qualified electrician before proceeding.

Technical Parameters

Model: WS-EU-RF / WS-US-RF
Voltage: 90-250V AC, 50/60Hz
Max. Current: 10A/Gang, Total 10A
Protocol: Wi-Fi 2.4GHz+RF433MHz
Frequency Band: 2.412 ~ 2.484GHz
Maximum Radio Transmit Power: <= 10dbm

Warnings:

Turn off the power at the circuit breaker and test that power is off before wiring.

Installation

Step 1: Remove the old switch.

Step 2: Verify power is off.

Step 3: Prepare to install wiring.

Step 4: Take pictures of the wiring diagram.

Step 5: Remove the panel with screwdriver.

Step 6: Prepare to install wiring.

Step 7: Put the switch into switch box.

Troubleshooting

How to reset Wi-Fi code

Remote radio frequency (RF) link method

Control your home with your voice

CE declaration of conformity

FCC compliance statement

This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Preparation for use

Download MOES App on App Store or scan the QR code

Registration or Log in

WARRANTY CARD

Product Information

Maintenance Records

Steps for connecting the APP to the device

Method One:

- Make sure your phone is connected to Wi-Fi and Bluetooth.
- Scan the QR code to configure the network guide.

Method Two:

- Enter Wi-Fi Password and click "Next".
- Press and hold the button for about 3 seconds.
- Open the MOES App, click the "+" in the upper right corner.

Gebruiksaanwijzing (Deutsch)

Beschreibung des Produkts

Einrichtung

Technische Parameter

Manuel de instrucciones (Español)

Descripción del producto

Instalación

Parámetros técnicos

Manuel d'instruction (Français)

Description du produit

Installation

Paramètres techniques

Manuale di istruzioni (Italiano)

Descrizione del prodotto

Installazione

Parametri tecnici

Manual de instruções (Português)

Descrição do produto

Instalação

Parâmetros técnicos

Руководство по эксплуатации (Русский язык)

Описание товара

Установка

Технические параметры

Preparation for use

Download MOES App on App Store or scan the QR code

Registration or Log in

WARRANTY CARD

Product Information

Maintenance Records

Steps for connecting the APP to the device

Method One:

- Make sure your phone is connected to Wi-Fi and Bluetooth.
- Scan the QR code to configure the network guide.

Method Two:

- Enter Wi-Fi Password and click "Next".
- Press and hold the button for about 3 seconds.
- Open the MOES App, click the "+" in the upper right corner.

Preparation for use

Download MOES App on App Store or scan the QR code

Registration or Log in

WARRANTY CARD

Product Information

Maintenance Records

Steps for connecting the APP to the device

Method One:

- Make sure your phone is connected to Wi-Fi and Bluetooth.
- Scan the QR code to configure the network guide.

Method Two:

- Enter Wi-Fi Password and click "Next".
- Press and hold the button for about 3 seconds.
- Open the MOES App, click the "+" in the upper right corner.

Preparation for use

Download MOES App on App Store or scan the QR code

Registration or Log in

WARRANTY CARD

Product Information

Maintenance Records

Steps for connecting the APP to the device

Method One:

- Make sure your phone is connected to Wi-Fi and Bluetooth.
- Scan the QR code to configure the network guide.

Method Two:

- Enter Wi-Fi Password and click "Next".
- Press and hold the button for about 3 seconds.
- Open the MOES App, click the "+" in the upper right corner.

Preparation for use

Download MOES App on App Store or scan the QR code

Registration or Log in

WARRANTY CARD

Product Information

Maintenance Records